

Camera and Windows

Symptom

The Logitech camera is indicated with a yellow triangle in Device Manager. Properties says: Code 39 errors:

Remedy 1

<https://answers.microsoft.com/en-us/windows/forum/all/code-39-error-for-imaging-devices/4eb5c500-7e37-4cda-b49a-234960b29c0c?page=3>

Remedy 2

If the problem is not solved by Remedy 1:

Start Windows/ Camera (the app) and, if it says “camera already in use’ (or the like), go to PRIVACY SETTINGS and allow other programs to use the camera.