


How to use the Casette

with the MkIV Duplimate

1. Place the Duplimate on a piece of foam-rubber. (4 pieces of foam-rubber are enclosed in the box which the Duplimate came in.) The Duplimate should be placed to the back of the foam-rubber as shown below:



The handle can be pulled to its outer position as soon as the machine has completed a duplicate. Once the handle is pushed to its inner position, the machine will start dealing the next duplicate. This gives you two possibilities:

- i. You can empty the cassette when the handle is in its outer position.
- ii. Or can you empty the cassette when the handle is in its inner position (while the machine prepares the next duplicate.)

The latter method is faster but it can be necessary to use the first method when the cards are new (i.e. slippery).

Note: If you need to remove the cassette, you must release it by pushing the levers (marked with red ink) when pulling it out.

JANNERSTEN FORLAG AB
BRIDGEAKADEMIN